


Product Installation guide




RECOMMENDED ROOM TEMPERATURE



120-277V~
50/60 Hz



RISK OF FIRE AND ELECTRICAL SHOCK




INSTALLATION INSTRUCTIONS

DISCLAIMER

Please read all instructions before beginning installation:


1. Turn off electrical power before starting the installation of the light fixture.
2. The feeding voltage must not exceed the specified fixture voltage.
3. This product must be installed by an eligible electrician.
4. Make sure the luminaire is mounted to a secure structure. Mounting the fixture in inappropriate way could lead to serious injury.
5. This luminaire is class 1, it must be earthed in a reliable way.
6. The light source of this luminaire shall only be replaced by the manufacturer, his service agent or a similar qualified person.
7. Wear gloves and safety glasses at all times when removing the luminaire from carton, installing, servicing or performing maintenance
8. Do not install damaged product! This luminaire is properly packed to avoid being damaged during transit. Inspect to confirm before installation. Any damaged or broken part during or after assembly should be replaced.
9. Unauthorized repairs or modifications will void warranty.

Section View:




Dimensions in inch

Applicable optics:




1. CutOff Washer



2. Opal & Prismatic


Product Installation guide

Dismantling the fixture



1 Use the scraper to remove the diffuser.


Handle and store the Components in a safe place.



2 Pull the LED Plate and detach the LED connector.

Fixing the Fixture

Mains Cable and fixation screws to be provided by the installer



Terminal Block Connection

Non Dimmable



L - Line
⊕ - Earth
N - Neutral

1-10V & Dali Dimmable


L - Line
⊕ - Earth
N - Neutral




DIM +
DIM -

- 3
- Insert the mains cable.
 - Fix the profile on the surface using appropriate screws.
 - Connect the wires in the terminal block.

Assembling the Fixture



- 4
- Join the LED connector.
 - Put the LED plate back in place.




- 5 Clip in the Diffuser in its place.



Make sure the clipping is done correctly and put in a way that won't damage the components.

Product Installation guide

For continuous Run




A

- Fix the first fixture in it's position.
- Install and fix the second fixture next to the first one.
- Slide the alignment bracket between the two fixtures and screws it.

B


- Join the electrical /control connectors together.

Annexe A



*Code Example:

- L3 I SM ----- I 48 I (Individual)
- L3 I SM----- I 48 B (Beginning)
- L3 I SM----- I 48 M (Middle)
- L3 I SM----- I 48 E (End)



Length Code*	L (inch) (Two End Caps)	L1 (inch) (One End Cap)	L2 (inch) (No End Cap)
12	12.01	11.83	11.65
24	23.58	23.41	23.23
36	35.16	34.98	34.80
48	46.73	46.56	46.38
60	58.31	58.13	57.95
70	69.88	69.74	69.53
82	81.46	81.32	81.10
93	93.03	92.89	92.68
105	104.61	108.33	100.39
116	116.18	116.04	115.83

*Code Example: L3 I SM ----- I 48 -



For the continuous make sure not to exceed 600W on a single feeding input.

Annexe B

Asymmetrical optics:

Below section views shows the light direction and the power feeding location for the asymmetrical optic.

