


# LIGHTWAY 6 - WALL RECESSED

## Product Installation Guide



**WARNING:**  
THE SAFETY OF THIS FIXTURE IS GUARANTEED ONLY WHEN COMPLYING WITH THE FOLLOWING INSTRUCTIONS



Electrical cables

Profile

Housing






### FOLLOW THE BELOW STEPS TO INSURE A PROPER INSTALLATION

STEP 1: Prepare a hole for the luminaire with the precise dimensions.

Applicable surfaces :

Concrete



# LIGHTWAY 6 - WALL RECESSED

## Product Installation Guide


### REFER TO THE TABLE FOR TYPICAL INSTALLATION PARAMETERS

Optic type	Distance between wall and fitting
Grazing	Between 10cm and 15cm (4" and 6") Depending on the wall texture
Washing	Between 1/5 and 1/6 of the wall height to be washed.
Other	Depending on the desired effect.


### NOTE:

- 1 - Always wear cotton gloves to avoid fingerprints mark on the product.
- 2 - Make sure to place all dismantled items in a safe and clean area to avoid any possible damage.
- 3 - LED should be protected from any possible electrostatic discharge (ESD) source.

**STEP 2:** Insert the luminaire electrical cable into the relative electrical tube and make the required connections (L + N + EARTH)



**STEP 3:** Clip-in the luminaire into the housing.



\* Make sure not to exceed the maximum allowable running length according to the below table:

Maximum running length through 1 feeding input												
System	Voltage	Power										
		L1 10 W/m	L2 15 W/m	L3 22 W/m	L4 30 W/m	L5 42 W/m	P1 20 W/m	P2 30 W/m	P3 42 W/m	M1 28 W/m	M2 40 W/m	M3 56 W/m
UL	120V~ 60 Hz	135 ft	100 ft	70 ft	50 ft	36 ft	70 ft	50 ft	36 ft	54 ft	38 ft	27 ft
CE	220-240V~ 50/60 Hz	62 m	45 m	33 m	23 m	17 m	33 m	23 m	17 m	25 m	18 m	13 m

### WARNING :

- THE FEEDING VOLTAGE SHOULD NOT EXCEED THE SPECIFIED FIXTUE VOLTAGE.
- DO NOT INSTALL THE FIXTURE IF DAMAGED
- UNAUTHORIZED REPAIRS OR MODIFICATIONS WILL VOID WARRANTY